

FRONT UPPER AND LOWER WISHBONES


1. Front Wishbone C.66804.
2. Upper Ball joint.
3. Lower Ball joint.
4. Lower Wishbone B.66815-6.
5. Metalastic Bush 13-935, Bolt D-67179, $\frac{5}{8}$ " B.S.F. Self-locking Nut.
6. Wishbone Pivot Cup D.66819, Metalastic Bush 13-935, Bolt D-67179, $\frac{5}{8}$ " B.S.F. Self-locking Nut, Wishbone Pivot Cup D.66819.

FRONT SUSPENSION WISHBONES

The front upper and lower wishbones are attached to the chassis points by rubber bushes. The recessed washers are inserted from the outside top wishbone with the mounting bolts inserted from inside the wishbone.

The recessed washers are inserted from inside the lower wishbone with the mounting bolt pushed through from outside.

PHOTOGRAPH FRONT SUSPENSION



582-1660