

-----Warning-----

Some CY-2562/PRC-25 battery boxes were fitted with four rubber battery support cushions. This was done to allow for the use of the half size BA-5598/U battery where one was connected to the radio and the other was a spare.

DO NOT INSTALL THE 257477BA Battery Adapter IN THESE BOXES UNTIL THE CUSHIONS HAVE BEEN PROPERLY RELOCATED!

The 257477BA has notches at each end designed to clear the two cushions used with the BA-4386/PRC-25 battery and other similar full size batteries. To confirm that the cushions are in the proper location sit an empty battery adapter into the battery box and look to see that the cushions are near the ends of the adapter and fully in the notched area of the adapter.

If the cushions are pressing on the center part of the adapter move the cushions toward the ends until they are fully in the notched portion.

